

Elise / Exige S2 Front Canards

Introduction

These front canards can be fitted just below the headlamps again to further tune the aero balance of the car.



Exige S2 with Front Spoiler & Canards

Notice raised centre to accelerate air into Rear diffuser

LOTUS DISCLAIMER





Although ReVerie Limited supply parts for use with/on vehicles manufactured by Lotus Cars Limited, ReVerie Limited is in no way connected to Lotus Cars Limited or any other member of the Lotus Group of companies ("Lotus") and is entirely independent of Lotus. Accordingly, none of the products offered for sale or supplied by ReVerie Limited (nor any advice or service offered or provided by ReVerie Limited) are in any way endorsed by Lotus and Lotus has not tested or approved any such products or services. Accordingly, Lotus shall not under any circumstances be liable for any loss, claim, damages or any consequential, indirect or special damages whatsoever arising out of or in connection with the use of products sold or supplied by ReVerie.

Tools Required

Metric spanner set
Metric socket set
Metric Ball end allen key set
Drill and drill bits
Sandpaper and block of various grits
Jack, Axle stands, wheel wrench

Parts supplied

Front canards
12* M5 10mm dia s/steel washers
6 * M5 but head s/steel bolts * 20mm
6* M5 s/steel nyloc nuts

| | |
|---|--|
|  | <p>1. Jack up the front of the car carefully as per Lotus handbook instructions and support on two axle stands safely.</p> |
|  | <p>2. Offer front canards in position and drill three fixing holes each side.</p> |
|  | <p>3. Having removed inner forward arch liners nyloc nut and bolt with supplied washers canards in place. Replace inner forward arch liners and lower car back onto ground safely.</p> |
|  | <p>Front View showing canards and optional wide s2 exige front spoiler (car fitted with wide arch flares)</p> |

WARNING, MOTORSPORT OR DRIVING CAN BE DANGEROUS RESULTING IN DEATH OR PERSONAL INJURY.

READ OUR FITTING INSTRUCTIONS CAREFULLY

This article is sold without warranty expressed or implied. No warranty or representation is made as to this product's ability to protect the user from injury or death. The user assumes that risk. The effectiveness, warranty and longevity of this equipment are directly related to the manner in which it is INSTALLED, USED, and/or MAINTAINED. THE USER ASSUMES THE RISK.

Fitment of REVERIE PRODUCTS TO AUTOMOBILES THAT ARE SUBJECT TO A MANUFACTURER'S WARRANTY MAY VOID THE MANUFACTURER'S WARRANTY AND THE VEHICLES ABILITY TO MEET EMISSION OR OTHER TRANSPORT REGULATIONS.

By purchasing this product and opening the packaging, purchasers expressly acknowledge, understand and agree that they take, select and purchase these REVERIE products from REVERIE, its affiliates, distributors, and agents (collectively, REVERIE) "as is" and "with all faults". The entire risk as to the quality and performance of these REVERIE parts is with the purchasers. Should the goods prove defective following their purchase; the purchasers assume the entire cost for all necessary servicing or repair or any resulting liability. Working on your car can be a dangerous activity. If you are unsure of what you are doing, please leave mechanical or Safety critical work to a skilled mechanic.

We take no responsibility for the incorrect use and / or installation of REVERIE products.

WWW.REVERIE.LTD.UK