

Elise S1 / Exige S1 Side Duct Fitting Guide

Introduction

In order to facilitate ram air to an induction system or more cooling air to alternator / gearbox etc reverie have produced moulded side scoops.

Contents:

LHS & RHS Carbon fibre side scoops

6 * M5 Alloy Rivserts / Nutserts

6 * M5 button head 60mm s/steel button head bolts

6 * M5 lotus Exige S1 s/steel side duct fitting body washers

U section perimeter rubber for around grille

Length of seat rubber edging for around carbon side scoop perimeter

Tools Required

Metric ball allen key set

Small dremel or flexi shaft from drill with a small 3mm burr cutting point

Posi bladed Screwdriver

LOTUS DISCLAIMER

Although ReVerie Limited supply parts for use with/on vehicles manufactured by Lotus Cars Limited, ReVerie Limited is in no way connected to Lotus Cars Limited or any other member of the Lotus Group of companies ("Lotus") and is entirely independent of Lotus. Accordingly, none of the products offered for sale or supplied by ReVerie Limited (nor any advice or service offered or provided by ReVerie Limited) are in any way endorsed by Lotus and Lotus has not tested or approved any such products or services. Accordingly, Lotus shall not under any circumstances be liable for any loss, claim, damages or any consequential, indirect or special damages whatsoever arising out of or in connection with the use of products sold or supplied by ReVerie.

Outer Scoops S1 Elise / S1 Exige



1. Offer scoop into position, then mark carefully through all three fixing holes to the body work.

Remove scoop and drill fibre glass at three points for M5 Rivserts * 3 off.
Fit the three rivserts to the GRP.



2. Fit scoop using M5 button heads and lotus stainless S1 exige side scoop washers supplied